



Watermiser™ Waterbroom

Models: WBI-21 (21”), WBI-31 (31”), WBI-36 (36”) & WBI-46 (46”)

How to Assemble

1. Remove the black thread protection cap from the end of the handle and attach handle to jet manifold.

Caution: Do **not** remove teflon tape from handle threads.

2. Carefully thread handle onto jet manifold until handle comes to a stop in the proper operating position.




How to Operate


1. Attach water hose to your Watermiser™ Waterbroom, turn on the water.

2. Start at the highest point and move towards the drain area.

3. Use your Watermiser™ Waterbroom by starting at the highest point of the slope (Fig. 1) following the pattern shown below for the most efficient cleaning and water conservation method (Fig. 2)



When operating your Watermiser™ Waterbroom, for best results, keep the rear wing parallel to the surface being cleaned.



WATERMISER™ WATERBROOM 5 YEAR LIMITED WARRANTY

Your Watermiser™ Waterbroom is warranted against manufactures defects and workmanship for five years from the date of purchase. If your Watermiser™ Waterbroom fails to operate properly within the first five years ship your Watermiser™ Waterbroom back to us for repair or replacement at our option. This warranty does not cover loss or damage of any kind resulting from alteration, misuse or abuse of the product. All returns must be approved by Watermiser Manufacturing Company. If you have any warranty questions call (800) 991-3419 or email sales@watermiser.com

Watermiser Manufacturing Company
1106 Second Street, #637, Encinitas, CA 92024
Telephone +1.800.991.3419 | Fax. +1.800.991.3418
www.watermiser.com

